



# TECHNICAL DATA SHEET SF 300 STRONG PARQUET ADHESIVE

## **PRODUCT:**

SF 300 STRONG is a solvent, and water-free universal parquet adhesive. Suitable for bonding many types of parquet floors onto suitable indoor substrates.

## **TECHNICAL DATA:**

Base	Polymer	
Curing system	Chemical curing	
Consistency Colour Specific gravity (DIN 53479) Brookfield viscosity (mPa.s) Open time at 21°C and 50% RH Adjustability time at 21°C and 50% RH Set to load bearing Sanding/finishing	Paste Light Oak Approx. 1,69 g/cm³ Approx. 56.000 mPa.s Approx. 40minutes Approx. 10-15 minutes min. 2 hrs min. 12 hrs	
Hardness Shore A	52	
Shear strength (EN14293) wood/wood	> 2 N/mm²	
Temperature resistance	-40°C to +90°C (cured)	
Durability against ageing	Good	
Total solids content	100% (solvent free)	
Application rate*	Depending on the subfloor 1000 – 1200 g/m² when using of the notched trowel (n°11) for parquet	

<sup>\*</sup> This varies according to ambient conditions such as temperature, humidity, substrate etc.

## **CHARACTERISTICS:**

- · Ready to use, no mixing required
- · Remains flexible
- · Single component ready to use system
- EC-1R Plus label: very low emission values
- Solvent free

<del>( • )</del>

- Contains no water
- Free of isocyanates
- Easy to apply
- Forms stable peaks when applied with a notched trowel or spreader comb
- Rapid cure and build up of final bond strength
- High final bond strength (according to EN14293)
- · Remains permanently elastic
- · Suitable for subfloor heating
- · Avoids staining of the hands

# **APPLICATIONS:**

 SF 300 STRONG is a solvent, and water-free universal parquet adhesive based upon Polymers. Suitable for indoor bonding of all types of wooden floors such as solid, stab, pre-finished, and on-end parquet, wood-planks up to 18cm wide, wood-block and laminates.

- Suitable for use on porous and non-porous substrates such as mosaic, anhydrite, concrete, screeds, wood, chipboard and OSB Board (large particle size chipboard), including floors with underfloor heating.
- SF 300 STRONG is also extremely suitable for bonding moisture sensitive wood onto moderately porous surfaces.

## **DESCRIPTION:**

SF 300 STRONG cures by means of a chemical reaction within the adhesive. Once fully cured (12- 24 hrs. at 21°C and 50% RH) an elastic and non-shrinking adhesive layer is formed, which is resistant to moisture and heat. The adhesive has excellent adhesion to most common substrates used in the construction industry.

SF 300 STRONG contains no water or solvents, minimising the risk of deforming the parquet to a minimum.

## **PACKAGING:**

- Colour: light oak (RAL1001)
- Packaging: 2 alu-bags in a cardboard box (2 x 7 kg = 14kg).
- The high-quality packaging guarantees an optimum shelf-life of the product. Separate packaging permits flexibility in use.

Remark: The directives contained in this documentation are the result of our experiments and of our experience and have been submitted in good faith. Because of the diversity of the materials and substrates and the great number of possible applications which are out of our control, we cannot accept any responsibility for the results obtained. In every case it is recommended to carry out preliminary experiments.



## Silva Floors

Vlimmersebaan 136, 2275 Wechelderzande, België +32 (0)14/39.59.96 • info@silvafloors.be • www.silvafloors.be

SF 300 STRONG - 2020/june

1





# TECHNICAL DATA SHEET SF 300 STRONG PARQUET ADHESIVE

## **SHELF-LIFE:**

At least 12 months in unopened packaging in a cool and dry storage place at temperatures between +5°C and +25°C.

## **SUBSTRATE:**

- Before installation of the parquet or timber flooring, the substrate should be checked to ensure it is suitable. Check the moisture content throughout the entire thickness of the substrate with a carbide or electric hygrometer. The acceptable moisture content must be as recommended by the flooring manufacturer (generally max. 2% for sand cement substrates and max. 0,5% for anhydrite, measured with a carbide hygrometer. For substrates with subfloor heating the values are resp. max. 1,5% and 0,3%)
- SF 300 STRONG should be applied to an even, stable, dry, clean and smooth substrate, which is free from irregularities and cracks. Rests of old adhesives may affect the adhesion and must be removed mechanically. Loose or damaged surfaces must be repaired before the application of the adhesive. If the subfloor is not even its needs to be levelled with a suitable levelling material
- Powdery surfaces can be treated (after consulting our technical service) with SF Primer.
  - Very porous surfaces can be treated (after consulting our technical service) with SF Primer.
  - Subfloors with a higher moisture content than described above can be treated (after consulting our technical service) with epoxy sealer.
- Smooth surfaces like anhydrite should be roughened and disposed of the top layer. Sanded subfloor must be vacuum cleaned with an industrial vacuum cleaner.
- When installing a parquet floor on top of marble, terrazzo or ceramic tiles they must be first cleaned with caustic soda or another suitable cleaner. Once cleaned, rinse the tiles thoroughly with plenty of clean water. Ensure the floor is completely dry before applying the SF 300 STRONG.

# A preliminary compatibility test is recommended on every surface.

Parquet	max. width (mm)	min. thickness (mm)
solid	180	20
engineered	300	14

The parquet flooring must be acclimatised for several days in the area where it is to be installed. Leave the parquet in its original packaging until installation to avoid any deformation.

Check before installation that the moisture content of the wood is as recommended by the supplier, (generally 9% +/- 2%). If the humidity of the wood is more than 11% installation is not recommended

Allow a gap of 1 to 1,5 cm around the perimeter of the laid parquet, including any columns or structures, which penetrate the floor.

## **APPLYING THE ADHESIVE:**

SF 300 STRONG should be acclimatised to room temperature before installation. Apply the adhesive to the surface by means of notched trowel N°11. For parquet sizes smaller than 60mm wide and 300mm long notched trowel N°3 is recommended. Do not apply more to the surface than can be covered with parquet within 40 minutes. Slide the parquet onto the adhesive layer and tap into place or tamp down with a rubber hammer.

A minimum of 80% contact coverage is required to ensure a perfect adhesion. Loading the parquet with weights will improve the final bond strength. Wait at least 12 hours before sanding and finishing the parquet.

Uncured SF 300 STRONG may be removed from tools and parquet with adhesive cleaner. Cured adhesive must be removed mechanically.

## **RECOMMENDATIONS:**

- Never install onto substrates, which are not protected against possible rising damp.
- Do not apply the adhesive at temperatures below 15°C or above 25°C
- Minimum temperature of the substrate should be at least 15°C.
- Do not apply the adhesive when the relative humidity is above 75%.
- Never install onto a substrate which contains too much moisture or onto substrates with a higher humidity value than recommended by the timber supplier.
- Never install timber which is too dry (<7% humidity). This type
  of timber can expand at higher humidity or when the humidity
  rises and cause damage.</li>
- Do not install if the walls and ceilings of the area are not dry (e.g. after plastering or painting etc.)
- Do not dilute the adhesive.

## **HEALTH- AND SAFETY RECOMMENDATIONS:**

Apply the usual industrial hygiene precautions. Consult the label for more information.





\*\*Information sur le niveau d'émission de substances volatiles dans l'air intérieur, présentan un risque de toxicité par inhalation, sur une échell de classe allant de A+ Itrès faibles émissions) à C (fortes émissions).

Remark: The directives contained in this documentation are the result of our experiments and of our experience and have been submitted in good faith. Because of the diversity of the materials and substrates and the great number of possible applications which are out of our control, we cannot accept any responsibility for the results obtained. In every case it is recommended to carry out preliminary experiments.



## Silva Floors

Vlimmersebaan 136, 2275 Wechelderzande, België +32 (0)14/39.59.96 • info@silvafloors.be • www.silvafloors.be

SF 300 STRONG - 2020/june

2